



Acousto-Optic Modulator Driver With Pulse Width Control

Including: Basic Modulator Alignment

Instruction Manual

760c Series – Digital Modulation, pulse OFF

770c Series – Digital Modulation, pulse ON

Key to model types : **76o.C-m-ff / 77o.C-m-ff**

Base model features TTL buffer compatible modulation input level and 24/28Vdc supply.

'o' indicates the base models standard frequency

1	:	40MHz
2	:	80MHz
3	:	110MHz
4	:	150MHz
5	:	200MHz

'C' indicates case style

and where appended,

'm' indicates options (combinations possible)

2	:	2 Watt output
4	:	4 Watt output
6	:	6 Watt output

L : +15V supply operation

'ff' indicates non-standard frequency e.g.

50	:	50MHz
120	:	120MHz



1. GENERAL

The 760C/ 770C series Digital Drivers are fixed frequency RF power sources specifically designed for use with Isomet acousto-optic modulators and Q-switches, operating at a fixed centre frequency. The driver accepts an digital (On:Off) modulating signal and provides a double-sideband amplitude modulated RF output to the acousto-optic modulator. Examples of popular driver specifications are listed below:

Model

762C-2 : 80MHz, 2.0W output, +24Vdc supply

773C-2 : 110MHz, 2.0W output, +24Vdc supply

Figure 2 is a block diagram of 760C / 770C series driver. The center frequency of the driver is determined by the free-running quartz-crystal oscillator. This frequency is accurate to ± 25 ppm and its stability is better than ± 25 ppm. The oscillator is not temperature stabilized.

A high-frequency, diode ring mixer is used to modulate the RF carrier according to the pulse width circuit triggered by the falling edge of the TTL input applied to the driver MOD input.

A MOD trigger input is 5V TTL compatible. A falling edge from >2.7 V to <0.6 volt will trigger the RF output pulse and result in 100% depth of modulation; ON to OFF for 760C series, OFF to ON for the 770C series. The duration of the pulse is set by the PW potentiometer control (counter-clockwise to increase).

The modulation input level must not exceed + 7 volts

The mixer output is applied to a MMIC pre-amplifier stage. This also serves to isolate the Oscillator and Mixer from the final power amplifier stage. The driver output power level is set by the Power adjust potentiometer at the input of this MMIC amplifier.

The amplitude-modulated MMIC output drives the input to a DMOS FET based power amplifier. This amplifier is designed to operate at full rated power into a 50Ω load with 100% duty cycle.



Figure 3 illustrates the principal waveforms of the Driver.

Conduction cooling of the driver from the mounting face to a heat sink or forced-air convection cooling is mandatory. The mounting face temperature must not exceed 70°C.

**SERIOUS DAMAGE TO THE AMPLIFIER MAY RESULT IF THE TEMPERATURE EXCEEDS 70°C.
SERIOUS DAMAGE TO THE AMPLIFIER MAY ALSO RESULT IF THE RF OUTPUT CONNECTOR
IS OPERATED OPEN-CIRCUITED OR SHORT-CIRCUITED.**

The drivers require a stable d-c power for operation. The required voltage is +24 / 28Vdc at a current drain of approximately 470mA EXCEPT model 7x0C-L. This lower power driver operates from 15Vdc. The external power source should be regulated to $\pm 2\%$ and the power supply ripple voltage should be less than 25mV for best results.

2. DIGITAL PULSE MODULATION

The 760/770C series drivers feature two multi-turn potentiometer controls:

PWR ADJ: The RF POWER ADJUST control sets the peak RF driver output level.
Clockwise to increase RF power.

PW: The PULSE WIDTH ADJUST control sets the output pulse width .

Counter-Clockwise to increase pulse width

Range: 0.25 – 4 usec

760C series = Output active, pulse width = RF OFF period.

770C series = Output off, pulse width = RF ON period.



3. INSTALLATION AND ADJUSTMENT

- 3.1 Install the Driver on a heat sink as shown in figure 1. Use heat conducting compound between the Driver and mounting face and the heat sink.
- 3.2 With no d-c power applied, connect the positive (+) DC to the center terminal of the feed-thru terminal as shown in figure 1. Connect the 0V or ground connection to the earth tab.
DO NOT APPLY POWER.

The standard models are internally regulated and can accept a wide supply voltage range of between +22V to +28Vdc, with no change in RF power.

For the higher power types 700C-4, or -6, the output power is supply dependent - see test data sheet supplied with unit.

DO NOT EXCEED +28Vdc or apply reverse polarity.

Also for the lower power type 700C-L, the output power is supply dependent.

DO NOT EXCEED +15Vdc or apply reverse polarity.

- 3.3 Connect the RF output SMA jack to an acousto-optic modulator (or 50Ω RF load, if it is desired to measure the modulator RF output power).
- 3.4 Connect a TTL signal source to the modulation 'MOD' input SMB jack
- 3.5 Adjustment of the RF output power is best done with Driver connected to the acousto-optic modulator. The Driver maximum output power is factory preset to a nominal level of approximately half maximum power.

The optimum RF power level required for the modulator to produce maximum first order intensity will be different at various laser wavelengths. Applying RF power in excess of this optimum level will cause a decrease in first order intensity (a false indication of insufficient RF power) and make accurate Bragg alignment difficult. It is therefore recommended that initial alignment be performed at a low RF power level.

- 3.6 If fitted, remove the PWR ADJ snap-in plugs from the driver case (see fig 1).
The PWR ADJ pot is a multi-turn type. Minimum power is when fully anti-clockwise (CCW).
With an insulated alignment tool or screwdriver:
Rotate the PWR ADJ potentiometer CCW at least 11 turns, then CW approx 5 turns.
- 3.7 Apply +15V, + 24V, or +28V DC power to the driver as appropriate for the model.
(see driver test sheet)
- 3.8 Connect a TTL pulse generator to the MOD trigger input .
(High > 2.7V, 10mA drive capability).
- 3.9 Set the PW control to maximum (CCW)
- 3.10 Observe the diffracted first-order output from the acousto-optic modulator and the undeflected zeroth order beam. Adjust the Bragg angle (rotate the modulator) to maximise first order beam intensity.

NOTE: Ideally use a high speed p-i-n diode and oscilloscope to observe the peak pulse intensity. If measuring average power, the reading will be factored by the RF duty cycle.
Duty cycle = MOD input rep rate x driver ON period

Driver ON period

760C series = 100% - PW setting

770C series = PW setting

Note: the peak diffraction efficiency may not exceed 20-30% at this point in the alignment procedure.

- 3.10 After the Bragg angle has been optimised, slowly increase the RF power (rotate PWR ADJ CW) until maximum peak first order intensity is obtained. This peaked RF drive level is termed the saturation power; P_{sat} . For applications using a well focussed input beam into the AOM, the correctly adjusted Bragg angle condition is indicated when the zero order shows a characteristic dark line through the middle of the beam at or near the P_{sat} drive level.
- 3.11 Set the PW control to the desired value (CW to reduce width) .



4. MAINTENANCE

4.1 Cleaning

It is of utmost importance that the optical apertures of the deflector optical head be kept clean and free of contamination. When the device is not in use, the apertures may be protected by a covering of masking tape. When in use, frequently clean the apertures with a pressurized jet of filtered, dry air.

It will probably be necessary in time to wipe the coated window surfaces of atmospherically deposited films. Although the coatings are hard and durable, care must be taken to avoid gouging of the surface and residue of the cleaning solution. It is suggested that the coatings be wiped with a soft ball of brushed (short fibres removed) cotton, slightly moistened with clean alcohol. Before the alcohol has had time to dry on the surface, wipe again with dry cotton in a smooth, continuous stroke. Examine the surface for residue and, if necessary, repeat the cleaning.

4.2 Troubleshooting

No troubleshooting procedures are proposed other than a check of alignment and operating procedure. If difficulties arise, take note of the symptoms and contact the manufacturer.

4.3 Repairs

In the event of deflector malfunction, discontinue operation and immediately contact the manufacturer or his representative. Due to the high sensitive of tuning procedures and the possible damage which may result, no user repairs are allowed. Evidence that an attempt has been made to open the optical head will void the manufacturer's warranty.




Figure 1: Driver Installation




Figure 2: Driver Block Diagram (Integral pulse width controller not shown)





Figure 3: Typical Pulsed Digital Modulation Waveforms

Schematic for an AO modulator with digital driver



The input Bragg angle, relative to a normal to the optical surface and in the plane of deflection is :

$$\theta_{BRAGG} = \frac{\lambda \cdot f_c}{2 \cdot v}$$

The separation angle between the zeroth order and the first order outputs is :

$$\theta_{SEP} = \frac{\lambda \cdot f_c}{v}$$

Optical rise time for a Gaussian input beam is approximated by :

$$t_r = \frac{0.65 \cdot d}{v}$$

- where : λ = wavelength
- f_c = centre frequency = 80MHz
- v = acoustic velocity of AO interaction material
 - = 4.21mm/usec (TeO₂)
 - = 3.63mm/usec (PbMoO₄)
 - = 5.96mm/usec (Fused Si)
- d = $1/e^2$ beam diameter

Figure 5: Modulation System